



ESD F-911 C-975 *Conductive*

VINYL BASED FOAM COATING

FOR INDUSTRIAL USE ONLY

DESCRIPTION:

F-911 C-975 is a *conductive* vinyl based coating used to seal unskinned polyurethane foams. F-911 C-975 can also be used on molded polyurethane and closed cell foam containing vinyl where ESD safe surfaces are needed.

OTHER FEATURES INCLUDE:

Excellent flexibility, scuff resistance [eliminates FOD], cushioning and non-skid properties.

SPECIFICATIONS:

Solids: (wt) 26%

Tensile: [ASTM D-412] 713psi

Elongation: [ASTM D-412] 364%

Temperature use range: -0°F to 200°F

Block Resistance: 4hr @ 140°F

Conductivity: 10/0- 10/4

Shelf life: 1+ year @ 77° f unopened container

Coverage: 80 sq. ft. per gallon at 5 mils

Finish: Satin

CHEMICAL RESISTANCE:ASTM D1308

Acids, alkalines, alcohols: Excellent

Petroleums: Good

Ketones: Limited

ALTERNATIVE PRODUCTS:

F-911 C-950

We cannot anticipate all conditions under which this information and our products, or the products of other manufacturers in combination with our products, may be used. We accept no responsibility for results obtained by the applications of this information or the safety and suitability of our products, either alone or in combination with other product combination for their own purposes. Unless otherwise agreed in writing, we sell the products without warranty, and buyers and users assume all responsibility and liability for loss or damage arising from the handling and use of our products whether used alone or in combination with other products. Ever changing V.O.C. regulations in your area may require you to contact local authorities for proper use and/or disposal of this product. Should you need further assistance, please contact PLASTI DIP INTERNATIONAL technical service.

SURFACE PREPARATIONS:

All surfaces to be coated must be free of any oils, dust or particles.

USE ADEQUATE VENTILATION.**MIXING INSTRUCTIONS:****QUALITY CONTROL RECOMMENDATIONS FOR SPRAY AND DIP APPLICATIONS.**

Like most liquid vinyls, F-911 may coagulate during storage, requiring thorough remixing agitation before use each day. For best results, a *high speed air/explosion proof electric drum mixer along with a Cowles® or other dispersion blade gives the maximum combination of high shear, excellent flow and circulation. Diameters of 3" for mixing five gallon containers and 7" for mixing 50 gallon drums. Note: It has been found that the dispersion blades are highly effective, fast and produce more shearing action than can be obtained from a standard mixing blade or paddle.

After the F-911 has been agitated thoroughly, it should last 8 to 10 hours depending on your spray equipment and temperature.

Avoid making solvent additions before mixing. Check viscosity. Some adjustments may be necessary for your particular use. Contact technical service for specific applications.

If applying to open cell foam follow Prime, Seal and Finish steps. If applying to non-porous surfaces follow Finish step only.

Prime coat: Set pot pressure at 20-25psi and atomizing at 30-50psi, open pattern adjustment for a 2"- 4" pattern at 6"-10" from surface. Aim spray gun at foam and fully trigger spray gun. Open material adjustment until a uniform, wet splatter appears on the foam. The wet splatter should melt or flow into the surface of the foam. Coat all sides (except bottom) with an overlapping motion. Make sure all corners and edges are thoroughly primed. The prime coat should be wet to the touch but should not completely color or cover the foam. Its purpose is to wet or prime the surface for the sealing coat, a necessity for proper adhesion.

Seal coat: After the prime coat has been applied, immediately begin sealing the foam by only partially pulling the trigger back from its previous setting until a dry, web coating appears. This seal coat should appear lighter in color than the prime coat. Hold gun approximately 6"-10" from surface and use an overlapping motion, being sure to **completely** seal the surface. If seal coat is applied too dry, poor adhesion will result. If applied too wet, sealing surface may become difficult. Again, seal all sides (except bottom), being sure to **check entire surface for complete seal.**

Finish coat: After seal coat has been applied, immediately begin applying the finish coat by fully triggering spray gun as in prime coat. Holding the gun 6"-10" from surface, apply a uniform splatter coat using an overlapping motion. Apply the finish coat as desired in thickness and texture. The finish coat is necessary to increase seal coat strength and durability. Allow the finished coated part to dry to the touch (see caution), minimum 5 minutes, then return to prime coat, seal coat, and finish coat bottom of part. Follow instructions and be sure to pay close attention to corners and edges on all steps.

NOTE: To accelerate final drying, place coated object in ventilated oven at 100°F-140°F for 5 minutes. Make sure heat source is safe for this use and that you ventilate properly. To increase coating speed, you may increase atomizing pressure; open material adjustment and pattern adjustment to your comfort level.

RECOMMENDED EQUIPMENT AND SETTINGS:

Binks® model 2100 gun

Nozzle: 66SS

Cap: 66SD

Needle: 565

Material: 25psi

Atomization: 30-50psi

Dilution: none required

Clean up: Acetone and Methyl Ethyl Ketone

HINTS: Always mix before **spraying**. Avoid excessive air movement, heat or humidity. Always use proper ventilation and protection.

REVISED 1/12/16
F-911 C-975 Conductive